Replace root disk on O2

Published 06/07/2001

Symptom(s):

System disk will not boot unix
System will boot to prom monitor
System disk does not show up in hinv
Bad system disk in the O2
Failed hard drive.

Fact(s):

IRIX 6.5.X
Silicon Graphics Indigo2
Silicon Graphics O2
IMPACT 10000

SGI Solution:

Replace system disk using following steps:

1. Shut down system
2. Remove bad root drive
3. Install new root drive
4. Install CD and boot miniroot
5. Install the IRIX OS.

Reference: Install IRIX 6.5

Answers others found helpful

- How to replace a failed drive on an SGI InfiniteStorage 220 (IS220) with an "Unassigned" drive

Additional Details

Creation Date	02/24/2000 11:33 AM
Last modification	01/15/2016 04:29 PM
Published Date	06/07/2001
Products	• Servers and Clusters • SGI Origin/Onyx • Origin/Onyx Server • Software • Legacy Software • Operating Systems • IRIX • Workstations • SGI Tezro • O2 • Octane
Categories	• Knowledgebase • Technical Solution